## **Cutter Maintenance**



**Preparation:** 


1 Lift and Remove Lever Cap




2 Remove Double Iron




3 Remove Cap Iron



SAFETY: Place Flat on Bench




**Blade Maintenance.** 



25°

Before use the Cutter must be honed or sharpened




Hone on a good quality Flat Oil Stone For assistance use: Honing Guide



Accepts: Plane Irons, Spokeshaves and Chisels.

4 Hold Cutting Iron at 30°



Use oil to keep the surface of the stone moist. Keep wrists rigid.


Wire Edge

Then rub off the fine wire edge formed by sharpening as shown below

O-5mm for fine finishing on hardwood 1-5mm for general purpose.

Re-assemble and Adjust for Use.

5 Remove Wire Edge





When to Grind a Cutting Iron





3 When the Cutting Edge is nicked



What is the size of the Grinding Angle?

Published by the Education Department 1983 set 3